

*The First Dual-Action Stimulator That Surges and Plunges Within You*

Lose yourself in waves of uncontrollable pleasure. In a world-first design, INA Wave™ is inspired by the caress of a lover's fingers, as it surges with a natural 'come-hither' motion to massage your G-Spot. While its generous body rises and falls, the powerful clitoral stimulator creates a blended climax that crashes over you. Housed in a 100% silicone design that is fully rechargeable and waterproof, the 10 unique vibration and wave settings deliver whole new levels of orgasm intensity.

## PRODUCT INFORMATION



**Cerise**  
7350075 021237



**Plum**  
7350075 021244



**Ocean Blue**  
7350075 021251

Product images available in ALL colors in our Retailer System ([www.lelo.com/retailer](http://www.lelo.com/retailer)).



## HOW TO USE

- Push the middle button to turn INA Wave™ on, and press the ^ or v button to cycle through the 10 stimulation modes.
- Press + to increase vibration strength and - to decrease.
- Push the middle button to turn off, and your last used setting will be saved, so that the next time INA Wave™ is turned on, it will start at that setting.
- With several vibrating components, the INA Wave™ is great for creative stimulation of erogenous zones during foreplay and beyond.
- The INA Wave™ has been programmed with 10 modes to combine vibrations with wave motion for intense intimate pleasure.
- To lock the INA Wave™ simply hold + and - buttons together until backlights turn off. To re-activate and turn on, hold + and - together until backlights turn on.

## SALES TIPS

- The 'come-hither' movement, in combination with the clitoral stimulator, mimic a lover's fingers to bring waves of uncontrollable pleasure.
- The intense sensations inside and out make it the most unique rabbit-style vibrator on the market.
- The visual impact of INA Wave™ make it a great suggestion for customers looking for a gift.
- With several vibrating components, the INA Wave™ is great for creative stimulation of erogenous zones during foreplay.
- Both the body and handle are 100% made of smooth and silk-touch silicone.
- INA Wave™ is 100% waterproof so it can be submerged in water completely for both pleasure and cleaning.

## TECHNICAL DATA

<b>Materials:</b> Body-safe silicone / ABS	<b>Standby:</b> 90 days
<b>Battery:</b> Li-Ion 850mA 3.7V	<b>Frequency:</b> 1Hz
<b>Charging:</b> 2h at 5.0V	<b>Max. Noise Level:</b> < 50dB
<b>User Time:</b> 2 Hours	<b>Interface:</b> 5-button interface

## SHIPPING & CASE PACK DETAILS

<b>Packing box size:</b> 326 x 110 x 57mm / 12.83 x 4.33 x 2.24in
<b>Shipping box:</b> 605 x 375 x 415mm / 23.82 x 14.96 x 16.34in
<b>Total units per final shipping box:</b> 20

Gain access to additional promotional material by becoming a registered LELO Retailer. Visit the Retailer section at [lelo.com](http://lelo.com) for more details.